



Door Lock Control



- * 2 : w/ Entry & Start System
- * 3 : w/o Entry & Start System


Door Lock Control

A73(A), D5(B), D6(C)
Main Body ECU




Door Lock Control


A73(A), D5(B), D6(C)
Main Body ECU



Door Lock Control


A73(A), D5(B), D6(C)
Main Body ECU






Door Lock Control


3B
White




3C
White




3D
White




AD1
White




AD2
White



ED1
White



ED2
White



Door Lock Control

FD1
White

1	2	3	4	5
6	7	8	9	10

5	4	3	2	1
10	9	8	7	6

FD2
White

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

11	10	9	8	7	6	5	4	3	2	1
22	21	20	19	18	17	16	15	14	13	12

GD1
White

1	2	3	4	5	6	7
8	9	10	11	12	13	14

7	6	5	4	3	2	1
14	13	12	11	10	9	8

HD1
White

1	2	3	4	5	6
13	14	15	16	17	18
31	32	33	34	35	36

7	8	9	10	11	12
22	23	24	25	26	27
40	41	42	43	44	45

12	11	10	9	8	7
30	29	28	27	26	25
48	47	46	45	44	43

6	5	4	3	2	1
21	20	19	18	17	16
39	38	37	36	35	34