























Position of Parts in Body <RHD>

* 3: Before Oct. 2011 Production
 * 4: From Oct. 2011 Production



- N 1 Outside Luggage Electrical Key Antenna
- N 2 Power Slide Back Door Warning Buzzer
- N 3 Front Door Courtesy Light Switch Assembly LH
- N 4 Rear Door Courtesy Light Switch Assembly LH
- N 6 Rear Combination Light Assembly LH
- N 7 Rear Height Control Sensor Sub-Assembly LH
- N 8 Curtain Shield Airbag Assembly LH
- N 11 Front Seat Outer Belt Assembly LH
- N 12 Curtain Shield Airbag Assembly LH
- N 13 Side Airbag Sensor Assembly LH
- N 14 Rear Indoor Electrical Key Oscillator
- N 15 No.2 Side Airbag Sensor Assembly LH
- N 16 Door Control Relay LH
- N 17 Fuel Lid Courtesy Switch
- N 18 Back Door Motor Unit
- N 19 Fuel Pump , Fuel Sender Gauge Assembly
- N 20 Front Floor Side Airbag Sensor
- N 21 Rear Floor Side Airbag Sensor
- N 26 Diode (Slide Door Courtesy Switch LH)
- N 27 Diode (Luggage Compartment Light)
- N 28 Junction Connector
- N 29 Junction Connector
- N 30 Junction Connector
- N 31 Junction Connector
- N 32 Junction Connector
- N 33 Multiplex Network Door ECU
- N 35 Rear No.3 Speaker Assembly LH
- N 36 Side Airbag Sensor Assembly LH
- N 37 No.2 Side Airbag Sensor Assembly LH

Position of Parts in Body <RHD>



Position of Parts in Body <RHD>

