




- K 1 Rear Power Window Regulator Switch Assembly RH
- K 2 Rear Power Window Regulator Motor Assembly RH
- K 3 Slide Door Lock Remote Control Assembly RH
- K 4 Rear Door Lock Assembly RH
- K 5 Door Control Relay RH
- K 6 Power Slide Door Sensor Assembly RH
- K 7 Slide Door Lock Release Motor Assembly RH
- K 8 Slide Door Handle Switch RH
- K 9 Door Side Airbag Sensor RH
- K 10 No.1 with Box Speaker Assembly RH
- K 12 Junction Connector
- K 13 Junction Connector
- K 14 Slide Door Closer Relay RH
- K 15 Rear No.2 Speaker Assembly RH

- L 1 Rear Power Window Regulator Switch Assembly LH
- L 2 Rear Power Window Regulator Motor Assembly LH
- L 3 Slide Door Lock Remote Control Assembly LH
- L 4 Rear Door Lock Assembly LH
- L 5 Door Control Relay LH
- L 6 Power Slide Door Sensor Assembly LH
- L 7 Slide Door Lock Release Motor Assembly LH
- L 8 Slide Door Handle Switch LH
- L 9 Door Side Airbag Sensor LH
- L 10 No.1 with Box Speaker Assembly LH
- L 12 Junction Connector
- L 13 Junction Connector
- L 14 Rear No.2 Speaker Assembly LH

Position of Parts in Body <RHD>

