



















Position of Parts in Instrument Panel <LHD>



- G 1 Headlight Dimmer Switch Assembly
- G 2 Transmission Control Switch
- G 3 Spiral Cable Sub-Assembly
- G 4 Spiral Cable Sub-Assembly
- G 5 Windshield Wiper Switch Assembly
- G 6 Windshield Wiper Switch Assembly
- G 7 Lower No.1 Instrument Panel Airbag Assembly
- G 8 DLC3
- G 10 Skid Control Buzzer Assembly
- G 11 Steering Sensor
- G 12 Windshield Wiper Relay Assembly
- G 13 Center Airbag Sensor Assembly
- G 15 ID Code Box
- G 16 No.1 Clearance Warning Buzzer
- G 17 Shift Lock Control ECU
- G 18 Power Steering ECU Assembly
- G 19 Combination Meter Assembly
- G 20 Certification ECU Assembly

Position of Parts in Instrument Panel <LHD>



Position of Parts in Instrument Panel <LHD>

