




- G 41 No.1 Glove Box Light Assembly
- G 42 No.2 Glove Box Light Assembly
- G 43 No.3 Glove Box Light Assembly
- G 46 Retractable Outer Mirror Switch
- G 47 Indicator Light Wire Sub-Assembly
- G 48 Main Body ECU
- G 49 Main Body ECU
- G 50 Main Body ECU
- G 51 Main Body ECU
- G 52 Junction Connector
- G 53 Junction Connector
- G 54 Junction Connector
- G 55 Junction Connector
- G 56 Junction Connector
- G 61 Junction Connector
- G 62 Junction Connector
- G 63 Junction Connector

Position of Parts in Instrument Panel <LHD>

