


Position of Parts in Instrument Panel <LHD>



- A 1 Stop Light Switch Assembly
- A 3 Accelerator Pedal Sensor Assembly
- A 4 Parking Brake Switch Assembly
- A 6 Stop Light Control Relay Assembly
- A 20 Power Steering ECU Assembly
- A 23 Headlight Swivel ECU Assembly
- A 30 Junction Connector
- A 31 Junction Connector
- A 38 Quick Heater Assembly
- A 39 Quick Heater Assembly
- A 44 Junction Connector
- A 45 Brake Pedal Load Sensing Switch
- A 47 Junction Connector
- A 48 Junction Connector

- H 1 Automatic Light Control Sensor
- H 2 Front No.3 Speaker Assembly RH
- H 3 Front No.3 Speaker Assembly LH
- H 4 Front Ion Generator Sub-Assembly
- H 5 Front Ion Generator Sub-Assembly
- H 6 Front No.2 Speaker Assembly
- H 7 Front No.3 Speaker Assembly RH
- H 8 Front No.3 Speaker Assembly LH











- M 22 Junction Connector
- M 28 Center Airbag Sensor Assembly

- N 24 Front Indoor Electrical Key Oscillator
- N 34 Center Airbag Sensor Assembly
- N 38 Rear Power Point Socket Assembly
- N 39 Video (Video Adapter) Terminal
- N 40 No.1 Stereo Jack Adapter Assembly
- N 41 Video (Video Adapter) Terminal


- c 1 Front Passenger Side Squib Circuit
- c 2 Front Passenger Side Squib Circuit

- z 5 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
- z 6 Cruise Control Main Switch , Spiral Cable Sub-Assembly
- z 7 Spiral Cable Sub-Assembly , Steering Pad Switch
- z 12 A/C Amplifier Assembly , A/C Blower Assembly
- z 13 Power Steering ECU Assembly , Power Steering Torque Sensor
- z 14 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 15 Power Steering ECU Assembly , Power Steering Motor Assembly














Position of Parts in Instrument Panel <LHD>



(Before Oct. 2011 Production)



(From Oct. 2011 Production)



Position of Parts in Instrument Panel <LHD>

