


Front Fender Apron LH

Front Fender Apron LH


(2AR-FE, 2GR-FE)



- * 1: ST NO.2 Relay (2AR-FE)
MG CLT Relay (2GR-FE)
- * 2: 40A DEF NO.1
- * 3: 30A PTC NO.2
- * 4: 40A BBC NO.2 (2AR-FE)
- * 5: 40A BBC NO.1 (2AR-FE)
- * 6: 50A ABS NO.1
- * 7: 30A ABS NO.2
- * 8: P/SEAT R/L NO.2
- * 9: P/SEAT R/L NO.1
- *10: 30A ST NO.2 (2AR-FE)
- *11: 30A PA-BBC (2AR-FE)
- *12: 5A IG2 NO.2 (2GR-FE)

Unit A

*13: 30A EFI-MAIN NO.2 (2GR-FE)
 *14: 30A EFI-MAIN NO.2 (2AR-FE)
 20A A/F HTR (2GR-FE)
 *15: 20A (2AR-FE)
 10A (2GR-FE)



(2GR-FKS)

