




Position of Parts in Instrument Panel (LHD : Before Jan. 2018 Production)




- F 1 Navigation Receiver Assembly
- F 2 Navigation Receiver Assembly
- F 3 Navigation Receiver Assembly
- F 4 Navigation Receiver Assembly
- F 5 Navigation Receiver Assembly
- F 6 Stereo Component Amplifier Assembly
- F 7 Stereo Component Amplifier Assembly
- F 8 Parking Assist ECU
- F 9 Parking Assist ECU
- F 16 Option Connector
- F 17 Option Connector
- F 18 Option Connector
- F 20 Navigation Receiver Assembly
- F 25 Parking Assist ECU
- F 28 Navigation Receiver Assembly
- F 29 Navigation Receiver Assembly
- F 30 Stereo Component Amplifier Assembly
- F 34 Navigation ECU
- F 35 Navigation ECU
- F 36 Navigation ECU
- F 37 Radio and Display Receiver Assembly
- F 38 Radio and Display Receiver Assembly
- F 39 Radio and Display Receiver Assembly
- F 40 Radio and Display Receiver Assembly
- F 41 Radio and Display Receiver Assembly
- F 42 Radio and Display Receiver Assembly
- F 43 Radio and Display Receiver Assembly
- F 44 Radio and Display Receiver Assembly
- F 45 Radio and Display Receiver Assembly




90980-10997




90980-10996



90980-12555




90980-12554




90980-12552




90980-12979




90980-12554




90980-12761




90980-12760




90980-10997




90980-10996




90980-12460




90980-12A71




90980-12593




90980-12A52



90980-12972



90980-12972



90980-12960

