


Position of Parts in Instrument Panel (RHD : Before Jan. 2018 Production)



- A 1 Stop Light Switch Assembly
- A 3 Accelerator Pedal Sensor Assembly
- A 32 Brake Pedal Load Sensing Switch (Brake Pedal Support Assembly)
- A 34 Fuel Pump Control ECU Assembly
- A 35 Option Connector
- A 36 Option Connector
- A 52 Atmospheric Pressure Sensor (Vacuum Sensor Assembly)
- A 58 Certification ECU (Smart Key ECU Assembly)
- A 59 Engine Stop and Start ECU
- A 60 Engine Stop and Start ECU
- A 62 No. 1 Junction Connector
- A 63 No. 2 Junction Connector
- A 64 No. 2 Junction Connector
- A 65 No. 3 Junction Connector
- A 67 Diode
- A 68 Diode
- A 69 No. 4 Junction Connector

