


Position of Parts in Seat (Rear No.1 Seat w/ Seat Position Memory)




- Y 2 Slide Lock Motor (Power Seat Motor Assembly RH)
- Y 3 Rear Seat Lock Open Lever Sub-Assembly RH
- Y 4 Rear Seat Climate Control ECU RH
- Y 5 Rear Seat Climate Control Blower RH
- Y 6 Seat Heater Assembly RH
- Y 8 Rear Power Seat Switch RH (Armrest)
- Y 9 Position Control ECU Assembly RH
- Y 10 Position Control ECU Assembly RH
- Y 11 Position Control ECU Assembly RH
- Y 12 Rear No. 1 Seat Inner Belt Assembly RH
- Y 13 Limit Switch (Power Seat Motor Assembly RH)
- Y 14 Occupant Detection Sensor (Rear Seat Cushion Pad RH)
- Y 16 Diode
- Y 17 Diode
- Y 18 No. 34 Junction Connector
- Y 19 No. 35 Junction Connector
- Y 22 Slide Lock Motor (Power Seat Motor Assembly LH)
- Y 23 Rear Seat Lock Open Lever Sub-Assembly LH
- Y 24 Rear Seat Climate Control ECU LH
- Y 25 Rear Seat Climate Control Blower LH
- Y 26 Seat Heater Assembly LH
- Y 28 Rear Power Seat Switch LH (Armrest)
- Y 29 Position Control ECU Assembly LH
- Y 30 Position Control ECU Assembly LH
- Y 31 Position Control ECU Assembly LH
- Y 32 Rear No. 1 Seat Inner Belt Assembly LH
- Y 33 Limit Switch (Power Seat Motor Assembly LH)
- Y 34 Occupant Detection Sensor (Rear Seat Cushion Pad LH)
- Y 36 Diode
- Y 37 Diode
- Y 38 No. 36 Junction Connector
- Y 39 No. 37 Junction Connector
- Y 41 Limit Switch (No. 1 Seat Back Frame Sub-Assembly LH)


Position of Parts in Seat (Rear No.1 Seat w/ Seat Position Memory)




90980-12471




90980-10824




90980-12444




90980-10797




90980-12365




90980-12371




90980-10997



90980-12557




90980-10801




90980-12365




90980-10795




90980-11987





90980-10962





90980-10962




90980-12372



90980-12372



90980-12471



90980-10824

Position of Parts in Seat (Rear No.1 Seat w/ Seat Position Memory)

