


F RELAY LOCATIONS

[Instrument Panel] (LHD Before May 2015 Production)

- * 1:w/ Entry & Start System
- * 2:w/o Entry & Start System
- * 3:Refer to the Service Bulletin for the installation position of the parts.



(LHD From May 2015 Production)

- * 1:w/ Entry & Start System
- * 2:w/o Entry & Start System
- * 3:Refer to the Service Bulletin for the installation position of the parts.
- * 4:w/ AFS
- * 5:w/o AFS

