





















Position of Parts in Instrument Panel <LHD Before May 2015 Production>

- * 1:w/ Entry & Start System
- * 7:Refer to the Service Bulletin
for the installation position of the parts.
- * 10:Before Nov. 2011 Production
- * 13:From Nov. 2011 Production Except Display Audio Type
- * 15:Before Feb. 2014 Production



- D 1 Radio Receiver Assembly
- D 2 Radio Receiver Assembly
- D 3 Antenna Amplifier Assembly
- D 4 Shift Lock Control ECU
- D 5 Spiral Cable Sub-Assembly
- D 6 Spiral Cable Sub-Assembly
- D 7 Headlight Dimmer Switch Assembly
- D 8 DLC3
- D 9 Skid Control Buzzer Assembly
- D 10 Airbag ECU Assembly
- D 12 Air Conditioning Control Assembly
- D 13 Electric Parking Brake Switch Assembly
- D 14 Driving Support ECU
- D 15 Radio Receiver Assembly
- D 16 Outer Mirror Switch Assembly
- D 17 Cigarette Lighter Assembly
- D 18 No. 1 Clearance Warning Buzzer
- D 19 Power Outlet Socket Assembly
- D 20 Airbag Cut Off Switch Cylinder Sub-Assembly
- D 21 Glove Box Light Assembly
- D 22 Navigation Receiver Assembly
- D 23 Navigation Receiver Assembly
- D 24 Navigation Receiver Assembly
- D 25 Navigation Receiver Assembly
- D 26 ID Code Box
- D 27 Power Tilt Motor
- D 28 Power Tilt Motor
- D 29 Blower Assembly
- D 30 Power Telescopic Motor
- D 31 Lower No. 1 Instrument Panel Airbag Assembly
- D 32 Room Temperature Sensor
- D 33 Windshield Wiper Switch Assembly
- D 34 Windshield Wiper Switch Assembly
- D 35 Headlight Swivel Main Switch

Position of Parts in Instrument Panel <LHD Before May 2015 Production>



Position of Parts in Instrument Panel <LHD Before May 2015 Production>

