


Position of Parts in Instrument Panel <LHD Before May 2015 Production>

- * 15: Before Feb. 2014 Production
- * 16: From Feb. 2014 Production
- * 17: From Feb. 2014 Production
Display Audio Type
- * 18: From Feb. 2014 Production
Extension Module Type



- A 1 Stop Light Switch Assembly
- A 2 Accelerator Pedal Sensor Assembly
- A 3 Clutch Start Switch Assembly
- A 4 Brake Pedal Stroke Sensor Assembly
- A 12 Stop Light Control Relay Assembly
- A 29 Power Steering ECU Assembly
- A 38 Headlight Swivel ECU Assembly
- A 39 Junction Connector
- A 44 Quick Heater Assembly
- A 45 Quick Heater Assembly
- A 52 Seat Belt Control ECU Assembly
- A 53 Seat Belt Control ECU Assembly
- A 66 Accelerator Pedal Sensor Assembly


- G 23 Airbag ECU Assembly

- H 12 Airbag ECU Assembly

- K 11 Junction Connector

- z 3 Air Conditioning Amplifier Assembly , Air Conditioning Blower Assembly
- z 4 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
- z 5 Spiral Cable Sub-Assembly
- z 6 Spiral Cable Sub-Assembly , Steering Pad Switch Assembly
- z 7 Front Passenger Side Squib Circuit
- z 8 Cruise Control Main Switch , Spiral Cable Sub-Assembly
- z 9 Key Inter Lock Solenoid
- z 10 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 11 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 12 Power Steering ECU Assembly , Power Steering Torque Sensor
- z 17 Extension Module
- z 18 Radio & Display Receiver Assembly
- z 19 Radio & Display Receiver Assembly
- z 20 Radio & Display Receiver Assembly
- z 21 Radio & Display Receiver Assembly
- z 22 Extension Module
- z 23 Extension Module

Position of Parts in Instrument Panel <LHD Before May 2015 Production>



Position of Parts in Instrument Panel <LHD Before May 2015 Production>

