























Position of Parts in Instrument Panel <RHD From May 2015 Production>

\* 8:w/ AFS  
\* 9:w/o AFS



- A 3 Clutch Start Switch Assembly
- A 4 Brake Pedal Stroke Sensor Assembly
- A 29 Power Steering ECU Assembly
- A 38 Headlight Swivel ECU Assembly
- A 44 Quick Heater Assembly
- A 45 Quick Heater Assembly
- A 66 Accelerator Pedal Sensor Assembly
- A 67 Stop Light Switch Assembly
- A 79 Engine Stop and Start ECU
- A 80 Engine Stop and Start ECU
- A 82 Headlight Leveling ECU Assembly
- A 85 Diode (No. 1 Pre-Crash Safety City Heater)
- A 86 Diode (No. 2 Pre-Crash Safety City Heater)
  
- G 66 Airbag ECU Assembly
  
- H 28 Airbag ECU Assembly
  
- z 3 Air Conditioning Amplifier Assembly , Air Conditioning Blower Assembly
- z 4 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
- z 5 Spiral Cable Sub-Assembly
- z 7 Front Passenger Side Squib Circuit
- z 8 Cruise Control Main Switch , Spiral Cable Sub-Assembly
- z 10 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 11 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 12 Power Steering ECU Assembly , Power Steering Torque Sensor
- z 20 Radio & Display Receiver Assembly
- z 21 Radio & Display Receiver Assembly
- z 22 Extension Module
- z 23 Extension Module
- z 24 Spiral Cable Sub-Assembly , Steering Pad Switch Assembly
- z 25 Driver Side Squib Circuit , Spiral Cable Sub-Assembly

Position of Parts in Instrument Panel <RHD From May 2015 Production>



Position of Parts in Instrument Panel <RHD From May 2015 Production>

