


Position of Parts in Body <RHD Wagon>





















H 1 Front Door Courtesy Light Switch Assembly RH
H 2 Front Pretensioner RH
H 3 Rear Door Courtesy Light Switch Assembly RH
H 4 Front Pre-Crash Seat Belt Motor RH
H 6 Side Airbag Sensor Assembly RH
H 8 Rear Airbag Sensor RH
H 9 Curtain Shield Airbag Assembly RH
H 14 Door Control Receiver
H 15 Theft Warning Siren Assembly
H 16 Indoor Luggage Compartment Electrical Key Oscillator
H 19 Outside Luggage Electrical Key Antenna
H 23 Glass Breakage Sensor (Quarter Glass RH)
H 24 Door Control Receiver
H 25 Rear Airbag Sensor RH
H 26 Side Airbag Sensor Assembly RH
H 27 Rear Seat 3 Point Type Belt Assembly Outer RH

I 1 Parking Brake ECU Assembly
I 2 Height Control Sensor Sub-Assembly

J 1 No. 1 Ultrasonic Sensor RH
J 2 No. 1 Ultrasonic Sensor Center RH
J 3 No. 1 Ultrasonic Sensor Center LH
J 4 No. 1 Ultrasonic Sensor LH

K 1 Visor Assembly RH
K 2 Visor Assembly LH
K 3 Vanity Light Assembly RH
K 4 Vanity Light Assembly LH
K 5 Rain Sensor
K 6 Inner Rear View Mirror Assembly
K 7 Map Light Assembly
K 8 No. 1 Room Light Assembly
K 9 Sliding Roof Control ECU
K 10 Lane Recognition Camera Sensor Assembly
K 12 Inner Rear View Mirror Assembly
K 13 Vanity Light Assembly RH
K 14 Vanity Light Assembly LH
K 15 Map Light Assembly
K 16 Pre-Crash Safety City Sensor
K 17 Pre-Crash Safety City Heater (Pre-Crash Safety City Heater Wire)

Position of Parts in Body <RHD Wagon>



Position of Parts in Body <RHD Wagon>

