









D1(A), D2(B), D127(G), D129(C)
Radio Receiver Assembly
D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)
Radio & Display Receiver Assembly



D1(A), D2(B), D127(G), D129(C)
Radio Receiver Assembly
D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)
Radio & Display Receiver Assembly



- * 1 : Display Audio Type
- * 2 : Except Display Audio Type
- * 4 : 6 Speaker
- * 7 : w/ Navigation System
- * 8 : w/o Navigation System
- * 12 : w/ Stereo Jack Adapter Assembly
- * 13 : Before Feb. 2013 Production
- * 14 : From Feb. 2013 Production
- * 15 : w/ Digital Audio Broadcasting


: There is no wire color information.

D1(A), D2(B), D127(G), D129(C)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)

Radio & Display Receiver Assembly




D1(A), D2(B), D127(G), D129(C)


Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)


Radio & Display Receiver Assembly




D133(A), z17(B), z22(C), z23(D)
Extension Module




D1(A), D2(B), D127(G), D129(C)
Radio Receiver Assembly
D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)
Radio & Display Receiver Assembly




D1(A), D2(B), D127(G), D129(C)
Radio Receiver Assembly
D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)
Radio & Display Receiver Assembly





D1(A), D2(B), D127(G), D129(C)
Radio Receiver Assembly
D123(F), D124(J), D125(D), D126(E), D128(H), D134(M), z18(K), z19(L), z20(N), z21(O)
Radio & Display Receiver Assembly

















A 39
White




A 42
Black




B 5
Gray




B 14
Gray



D 1
White




D 2
White




D 3
White




D 5
Black




D 39
White




D 40
White




D 51
White




D 52
White




D 53
White




D 66
Black




D 91
White








































D118
White



D119
White









(4B)

White




(DB)

White




(DC)

White




(DE)

White




(DH)

White




(DK)

White




(DM)

White




(DS)

White




AD5


White




AG2

White







ED5
White



FG1
White



FH1
White



KD1
White

