














Position of Parts in Instrument Panel <LHD From May 2015 Production>




- D 50 Power Steering ECU Assembly
- D 52 Front No. 2 Speaker RH
- D 53 Front No. 2 Speaker LH
- D 54 Certification ECU Assembly
- D 55 Front Indoor Electrical Key Oscillator
- D 56 Engine Switch
- D 57 Steering Lock Actuator Assembly
- D 59 Certification ECU Assembly
- D 60 Windshield Wiper Relay Assembly
- D 61 Hazard Warning Signal Switch Assembly
- D 64 Headlight Leveling Switch
- D 66 Combination Meter
- D 67 VSC Off Switch
- D 69 Yaw Rate Sensor
- D 74 Fuel Lid Opener Switch
- D 77 Diode (Front Door Courtesy Switch LH)
- D 78 Diode (Front Door Courtesy Switch RH)
- D 79 Main Body ECU
- D 80 Main Body ECU
- D 81 Main Body ECU
- D 88 Junction Connector
- D 89 Junction Connector
- D 91 Junction Connector
- D 92 Fuse Block
- D 93 Junction Connector
- D 94 Junction Connector
- D 95 Junction Connector
- D 98 Ignition or Starter Switch Assembly
- D 99 Un-Lock Warning Switch Assembly






Position of Parts in Instrument Panel <LHD From May 2015 Production>



(Before Oct. 2016 Production)




(From Oct. 2016 Production)




D 79

White




D 80

White




D 81

White




D 88

White




D 89

White




D 91

White




D 92



D 93

White




D 94

White




D 95

White



D 98

White



D 99

White

