








D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly




- * 1 : Display Audio Type
- * 2 : Except Display Audio Type
- * 3 : 11 Speaker
- * 4 : 6 Speaker
- *20 : 10 Speaker

D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly




D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly




D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly



- * 1 : Display Audio Type
- * 2 : Except Display Audio Type
- * 3 : 11 Speaker
- * 4 : 6 Speaker
- * 5 : w/o Navigation System
- * 6 : w/ Navigation System
- *14 : w/ Stereo Jack Adapter Assembly
- *18 : Before May 2015 Production
- *19 : From May 2015 Production
- *20 : 10 Speaker

: There is no wire color information.




D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly




D1(A), D2(B), D119(C), D127(G), D163(P)

Radio Receiver Assembly

D123(F), D124(J), D125(D), D126(E), D128(H), D133(M), D164(Q), z18(K), z19(L), z22(N), z23(O)

Radio & Display Receiver Assembly





D132(A), D165(E), z17(B), z21(C), z24(D)
Extension Module


- * 1 : Display Audio Type
- * 3 : 11 Speaker
- * 5 : w/o Navigation System
- * 6 : w/ Navigation System
- *15 : Before Feb. 2014 Production
- *16 : From Feb. 2014 Production
- *18 : Before May 2015 Production
- *19 : From May 2015 Production
- *20 : 10 Speaker


: There is no wire color information.

























































(Before Oct. 2016 Production)





(From Oct. 2016 Production)














FG1
White




FH1
White



KD1
White



LG4
White



LM4
White

