







Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>



Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>





Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>





- * 8 : Before Jun. 2010 Production
- * 9 : From Jun. 2010 Production
- * 10 : From Jun. 2010 Production until Sep. 2010 Production
- * 11 : From Sep. 2010 Production
- * 12 : Before Nov. 2011 Production
- * 13 : From Nov. 2011 Production
- * 19 : Before May 2015 Production
- * 20 : From May 2015 Production
- * 21 : From Jun. 2010 Production until May 2015 Production

Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>













Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>







D79(A), D80(B), D81(C)
Main Body ECU









A 34
Gray




A 39
White




A 41
Black




A 42
Black




A 43
Black




A 68
Black



A 69
Black




D 66
Black




(Before Oct. 2016 Production)

D 66
White




(From Oct. 2016 Production)


D 79
White




D 80
White




D 81
White




D 82
Black




D 86
Black



D 87
Black




D 90
Gray




D 99
White




D106
Blue




D112
White




D113
White




D114
White




D117
White




D130
White




D138
Gray




















D140
Black



Door Lock Control , Wireless Door Lock Control <w/o Entry & Start System>









AD7



Blue



AD10



Blue

White





AG2

White





DG1

White





DG3

White





DG4

White




DG5


White




DH1
Gray




DH4
White




DH5
White




ED1
Blue




ED2
White




ED4
Blue




ED5
White




ED7
White




ED8
White




FG1
White



FH1
White



LG1
Blue



LG2
White

