



- * 1:1KR-FE
- * 2:2WZ-TV
- * 6:Before Feb. 2012 Production
- * 7:From Feb. 2012 Production
























A 17 Stop Lamp SW
A 17 Stop Lamp SW
A 22 Combination Meter
A 23 Accelerator Position Sensor
A 27 Multi-mode Manual Transmission ECU
A 28 Multi-mode Manual Transmission ECU
A 29 Multi-mode Manual Transmission ECU
A 30 Junction Connector
A 37 Accelerator Position Sensor
A 38 Junction Connector
A 40 Skid Control Resistor
A 42 Junction Connector
A 43 Clutch Start Switch Assembly
A 47 Skid Control Resistor
A 49 Multi-mode Manual Transmission ECU
A 50 Multi-mode Manual Transmission ECU

C 1 Combination Meter
C 2 Tachometer
C 3 Speaker (Front LH)
C 4 A/C SW
C 5 Combination SW
C 6 Spiral Cable
C 7 Combination SW
C 8 Combination SW
C 9 Blower SW
C 10 Speaker (Front RH)
C 11 Hazard Warning Signal SW
C 12 Rear Window Defogger SW
C 13 Ignition SW
C 14 A/C Amplifier
C 15 Power Outlet Socket
C 16 DLC3
C 17 Radio Receiver Assembly
C 18 Radio Receiver Assembly

Position of Parts in Instrument Panel <RHD>



(1KR-FE M/T w/o VSC)



Position of Parts in Instrument Panel <RHD>

