


Charging

- * 1 : w/ Battery Current Sensor Assembly
- * 2 : w/o Battery Current Sensor Assembly
- * 3 : 8NR-FTS
- * 4 : 3ZR-FAE



6 C-HR (Cont' d)

Charging

