























Position of Parts in Body (RHD)




* 1:Australia
* 2:Except Australia

I1	Front No. 1 Speaker Assembly RH
I2	Front Power Window Regulator Motor Assembly RH
I3	Front Door Outside Handle Assembly RH
I4	Front Door Lock with Motor Assembly RH
I5	Door Side Airbag Sensor RH
I6	Multiplex Network Master Switch Assembly
I7	Outer Rear View Mirror Assembly RH
I8	Outer Rear View Mirror Assembly RH
I11	No. 1 Interior Illumination Light Assembly RH
I12	Outer Mirror Switch Assembly
J1	Front No. 1 Speaker Assembly LH
J2	Front Power Window Regulator Motor Assembly LH
J3	Front Door Outside Handle Assembly LH
J4	Front Door Lock with Motor Assembly LH
J5	Door Side Airbag Sensor LH
J7	Outer Rear View Mirror Assembly LH
J8	Front Power Window Regulator Switch Assembly LH
J9	No. 1 Interior Illumination Light Assembly LH
J11	Outer Rear View Mirror Assembly LH
K1	Rear Door Lock with Motor Assembly RH
K2	Rear Power Window Regulator Motor Assembly RH
K3	Rear Power Window Regulator Switch Assembly RH
K4	Rear Speaker Assembly RH
L1	Rear Door Lock with Motor Assembly LH
L2	Rear Power Window Regulator Motor Assembly LH
L3	Rear Power Window Regulator Switch Assembly LH
L4	Rear Speaker Assembly LH


Position of Parts in Body (RHD)




Position of Parts in Body (RHD)




90980-12550




90980-10935




90980-12226



90980-12328



90980-12550



90980-10935