
Connector Joining Wire Harness and Wire Harness



Code	Joining Wire Harness and Wire Harness (Connector Location)
BA1	Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar)
BB1	Rear Door RH Wire and Floor Wire (Right Center Pillar)