

Door Lock Control (RHD)




B 5(A), B 7(C)
Body ECU
SGND
GND
KSW
L1
UL1
L2
ACTD
UL2
LSWD
＊1 : w/ Double Locking
＊2 : w/o Double Locking
U 1
Unlock Warning SW
D13
Door Lock Control SW
Front RH
Lock
Unlock
D11
Door Key Lock and Unlock SW Front RH
Door Lock Motor Front RH
Door Unlock Detection SW Front RH
L
UL
UL
LSSR
L
E
B 3
B 3
IK
IN
BP
BR
L
LG
G–R
L–Y
L–B
L–W
Y
L–R
W–B
SB

Door Lock Control (RHD)

