

(Cont. next page)
ECT and A/T Indicator (2AZ–FE, 1AZ–FE)
Power Source
9 CAMRY
* 1 : LHD Europe
E 6(A), E 7(B), E 8(C), E 9(D), E10(E)
Engine and ECT ECU (A/T)
Engine Control System<7–6><7–7>
Engine Control System<7–8><7–9>
C 2
Counter Gear Speed Sensor
T 3
Turbine Speed Sensor
E1
ECT Solenoid
A21
O/D Main SW
K 4
Kick Down SW
J 1
Junction Connector
J 2
Junction Connector
I15
Ignition SW
EFI Relay
IG1 Relay
10A IG2
20A EFI
30A AM2
5A AM1
10A GAUGE2
100A ALT
Battery
FL MAIN 2. 0W
Intake Side of Cylinder Block
Left Side of Cylinder Head
Left Fender
Instrument Panel Reinforcement RH
Cowl Side Panel LH
(RHD)
(LHD)

9 CAMRY (Cont' d)

