



(Cont. next page)
Engine Immobiliser System (1MZ–FE)
Power Source
6 CAMRY
A/F HTR Relay
C/OPN Relay
EFI Relay
15A IGN
10A IG2
20A EFI
25A A/F
30A AM2
10A ETCS
7. 5A OBD
J 7 Junction Connector
J 2 Junction Connector
J11 Junction Connector
I14 Transponder Key Amplifier
I15 Ignition SW
F12 Fuel Pump
120A ALT
FL MAIN 3. 0W
Battery
Cowl Side Panel LH
Instrument Panel Reinforcement RH
Left Fender
Front Side of Rear Quarter Wheel House LH

6 CAMRY (Cont' d)

(Cont. next page)



(Cont. next page)



6 CAMRY (Cont' d)

