

(Cont. next page)
ECT and A/T Indicator (1MZ–FE)
Power Source
8 CAMRY
* 1 : LHD Europe
E 6(A), E 7(B), E 8(C), E 9(D), E10(E)
Engine and ECT ECU (A/T)
C 2
Counter Gear Speed Sensor
T 3
Turbine Speed Sensor
A21
O/D Main SW
K 4
Kick Down SW
J 1
Junction Connector
E 1
ECT Solenoid
I15
Ignition SW
EFI Relay
IG1 Relay
20A EFI
30A AM2
5A AM1
10A GAUGE2
120A ALT
FL MAIN
3. 0W
Battery
Surge Tank RH
Rear Side of Surge Tank
Left Fender
Instrument Panel Reinforcement RH
Cowl Side Panel LH
Engine Control System<6–7><6–8>
Engine Control System<6–11><6–12>

8 CAMRY (Cont' d)

