

Auto Antenna
Power Source
Radio and Player <30–4>
Radio and Player with Display<29–4>
J 5(A), J 6(B) Junction Connector
A35 Auto Antenna Control Relay
Front Side of Rear Quarter Wheel House RH
10A GAUGE1
10A RAD NO. 2
ACC Relay
IG1 Relay
5A AM1
20A RAD NO. 1
30A D. C. C
120A ALT
FL MAIN 3. 0W
Battery
I15 Ignition SW
Instrument Panel Reinforcement RH
Cowl Side Panel LH
(LHD)
(RHD)