
Position of Parts in Body

[RHD]



L 1 License Plate Light LH
L 2 License Plate Light RH
L 3 Light Failure Sensor
L 4 Luggage Compartment Door Opener Motor
Luggage Compartment Light SW
L 5 Luggage Compartment Light

M 1 Mirror Heater LH
Remote Control Mirror LH
M 2 Mirror Heater RH
Remote Control Mirror RH
M 3 Moon Roof Control ECU and Motor
M 4 Moon Roof Control SW
Personal Light

N 4 Noise Filter

P 6 Power Window Control SW Front LH
P 8 Power Window Control SW Rear LH
P 9 Power Window Control SW Rear RH
P10 Power Window Motor Front LH
P11 Power Window Motor Front RH
P12 Power Window Motor Rear LH
P13 Power Window Motor Rear RH
P14 Pretensioner LH
P15 Pretensioner RH

R12 Rain Sensor
R13 Rear Combination Light LH
R14 Rear Combination Light RH
R15 Rear Speaker LH
R16 Rear Speaker RH
R17 Rear Window Defogger
R18 Rear Window Defogger
R19 Remote Control Mirror SW

S15 Side Airbag Sensor Front LH
S16 Side Airbag Sensor Front RH
S21 Side Airbag Sensor Rear LH
S22 Side Airbag Sensor Rear RH

V 7 Vanity Light LH
V 8 Vanity Light RH

Z 3 Option Connector (TVSS Siren)