

5 CAMRY
Power Source
Charging
1
2
3
4
5A AM1
10A GAUGE1
IG1 Relay
10A IG2
C 7 Combination Meter
Charge
5A ALT–S
30A AM2
I15 Ignition SW
ACC
IG1
ST1
IG2
ST2
AM1
AM2
Cut Off
120A ALT
FL MAIN 3. 0W
Battery
A15(A), A16(B) Alternator
Cowl Side Panel LH
Instrument Panel Reinforcement RH
(LHD)
(RHD)