

Audio System (w/o Navigation System)
Power Source
* 1 : Turkey
* 2 : Except Turkey
R16 Rear Speaker RH
R15 Rear Speaker LH
C10 Combination SW
Steering Pad SW
MODE
Volume–
Volume+
Seek–
Seek+
R 2(A), R 3(B), R 4(C), R 5(D), R24(E), R25(F) Radio and Player
T 7 Tweeter RH
T 6 Tweeter LH
F11 Front Door Speaker RH
F10 Front Door Speaker LH
Auto Antenna Control Relay <30–4>
J 5(A), J 6(B) Junction Connector
Instrument Panel Brace RH
Cowl Side Panel LH
Instrument Panel Reinforcement RH
10A RAD NO. 2
ACC Relay
5A AM1
I15 Ignition SW
120A ALT
FL MAIN 3. 0W
Battery
20A RAD NO. 1
30A D. C. C