



MANUAL TRANSMISSION/TRANSAXLE

0237A–01

PREPARATION

Recomended Tools

	09011–12301	Socket Wrench 30 mm	MANUAL TRANSAXLE ASSY(From July, 2003)
	09040–00011	Hexagon Wrench Set	MANUAL TRANSAXLE ASSY(From July, 2003)
	(09043–20060)	Socket Hexagon Wrench 6	MANUAL TRANSAXLE ASSY(From July, 2003)
	(09043–20060)	Socket Hexagon Wrench 6	MANUAL TRANSAXLE ASSY(From July, 2003)

Equipment

Torque wrench	

Lubricant

Item	Capacity	Classification
Manual transaxle oil (w/ Differential oil)	2.5 liters (2.6 US qts, 2.2 lmp. qts)	API GL–4 or GL–5 SAE 75W–90