
DISPLAY PANEL DOES NOT OPEN, TILT, OR TILTS IMPROPERLY

INSPECTION PROCEDURE

1	CHECK RADIO AND NAVIGATION ASSY



(a) Check for foreign matter or obstructions caught in the moving parts of the panel.
Standard: No obstruction or foreign matter is found.

NG → **REMOVE ANY OBSTRUCTION OR FOREIGN MATTER FOUND**

OK

2	OPERATION CHECK

(a) Check if the navigation and audio systems function properly.
Standard: Navigation and audio systems function properly.

OK → **REPLACE RADIO AND NAVIGATION ASSY (SEE PUB. NO. RM915E, PAGE 67–4)**

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05–46)