050YF–40

HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester II can be used in steps 4, 6, 8 and 9.

1	VEHICLE BROUGHT TO WORKSHOP

NEXT

2	CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05–9)

NEXT

3	WARNING LIGHT CHECK (SEE PAGE 05–10)

NEXT

4	DTCs CHECK (Present and Past DTCs) (SEE PAGE 05–16)

	DTCs ARE OUTPUT (INCLUDING NORMAL SYSTEM CODE): Go to step 5
	DTCs ARE NOT OUTPUT: PROBLEM SYMPTOMS TABLE (SEE PAGE 05–23)

5	DTCs CHART (SEE PAGE 05–24)

NEXT

6	CIRCUIT INSPECTION (SEE PAGE 05–29 TO 05–208)

NEXT

7	REPAIR

NEXT

8	CLEAR DTCs (Present and Past DTCs) (SEE PAGE 05–16)

NEXT

9	DTCs CHECK (Present and Past DTCs) (SEE PAGE 05–16)

	DTCs ARE NOT OUTPUT: Go to step 10
	DTCs ARE OUTPUT: Go to step 5

10	SYMPTOM SIMULATION (SEE PAGE 01–21)

WARNING LIGHT REMAINS OFF: Go to step 11

WARNING LIGHT IS ON: Go to step 5

11	CONFIRMATION TEST

NEXT

END