05MDJ–01

CHECK MODE PROCEDURE

1. CHECK MODE (SIGNAL CHECK) (USING INTELLIGENT TESTER II)

(a) Connect the intelligent tester II to the DLC3.

(b) Turn the ignition switch to the ON position.

(c) Select the ”SIGNAL CHECK”, and proceed checking with the intelligent tester II.