
2805T–01

HOW TO PROCEED WITH TROUBLESHOOTING

1. DIAGNOSIS OF TIRE VIBRATION



2. IRREGULAR TIRE WEAR

