DIAGNOSTICS



PREPARATION



020Y3–01

SST

	09816–30010	Oil Pressure Switch Socket	EFI SYSTEM(1AZ–FE) EFI SYSTEM(2AZ–FE)
	09843–18040	Diagnosis Check Wire No.2	AIR CONDITIONING SYSTEM ABS WITH BA & EBD SYSTEM ABS WITH EBD & BA & TRC & VSC SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM COMBINATION METER EFI SYSTEM(1AZ–FE) EFI SYSTEM(1MZ–FE) EFI SYSTEM(2AZ–FE)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE[ECT] SUPPLEMENTAL RESTRAINT SYSTEM WIPER AND WASHER SYSTEM LIGHTING SYSTEM EFI SYSTEM(1AZ–FE) EFI SYSTEM(1MZ–FE) EFI SYSTEM(2AZ–FE)
	(09083–00150)	Test Lead Set	AIR CONDITIONING SYSTEM ABS WITH BA & EBD SYSTEM ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE[ECT] ABS WITH EBD & BA & TRC & VSC SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM WIPER AND WASHER SYSTEM LIGHTING SYSTEM AUDIO SYSTEM NAVIGATION SYSTEM POWER WINDOW CONTROL SYSTEM POWER DOOR LOCK CONTROL SYSTEM WIRELESS DOOR LOCK CONTROL SYSTEM ENGINE IMMOBILISER SYSTEM BODY MULTIPLEX COMMUNICATION SYSTEM CRUISE CONTROL SYSTEM COMBINATION METER EFI SYSTEM(1AZ–FE) EFI SYSTEM(1MZ–FE) EFI SYSTEM(2AZ–FE)

 (09083–00150) Test Lead Set	AIR CONDITIONING SYSTEM ABS WITH BA & EBD SYSTEM ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE[ECT] ABS WITH EBD & BA & TRC & VSC SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM WIPER AND WASHER SYSTEM LIGHTING SYSTEM AUDIO SYSTEM NAVIGATION SYSTEM POWER WINDOW CONTROL SYSTEM POWER DOOR LOCK CONTROL SYSTEM WIRELESS DOOR LOCK CONTROL SYSTEM ENGINE IMMOBILISER SYSTEM BODY MULTIPLEX COMMUNICATION SYSTEM CRUISE CONTROL SYSTEM COMBINATION METER EFI SYSTEM(1AZ–FE) EFI SYSTEM(1MZ–FE) EFI SYSTEM(2AZ–FE)
 (09083–00150) Test Lead Set	AIR CONDITIONING SYSTEM ABS WITH BA & EBD SYSTEM ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE[ECT] ABS WITH EBD & BA & TRC & VSC SYSTEM SUPPLEMENTAL RESTRAINT SYSTEM WIPER AND WASHER SYSTEM LIGHTING SYSTEM AUDIO SYSTEM NAVIGATION SYSTEM POWER WINDOW CONTROL SYSTEM POWER DOOR LOCK CONTROL SYSTEM WIRELESS DOOR LOCK CONTROL SYSTEM ENGINE IMMOBILISER SYSTEM BODY MULTIPLEX COMMUNICATION SYSTEM CRUISE CONTROL SYSTEM COMBINATION METER EFI SYSTEM(1AZ–FE) EFI SYSTEM(1MZ–FE) EFI SYSTEM(2AZ–FE)