




FUEL




PREPARATION




020VZ–01

SST

	09268–41047	Injection Measuring Tool Set	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	(09268–41110)	Adaptor	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	(09268–41300)	Clamp	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	(95336–08070)	Hose	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	(90467–13001)	Clip	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	09842–30070	Wire ”F” EFI Inspection	FUEL SYSTEM(1MZ–FE)
	(95333–06030)	Hose	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)
	09842–30080	Wire ”H” EFI Inspection	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(2AZ–FE)
	(95333–06030)	Hose	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)

Recomended Tools

	09040–00011	Hexagon Wrench Set	FUEL INJECTOR ASSY(1MZ–FE)
	(09043–20050)	Socket Hexagon Wrench 5	FUEL INJECTOR ASSY(1MZ–FE)
	(09043–20080)	Socket Hexagon Wrench 8	FUEL INJECTOR ASSY(1MZ–FE)

	(09043–20050) Socket Hexagon Wrench 5	FUEL INJECTOR ASSY(1MZ–FE)
	09082–00040 TOYOTA Electrical Tester	FUEL SYSTEM(1MZ–FE)
	(09083–00150) Test Lead Set	FUEL SYSTEM(1AZ–FE) FUEL SYSTEM(1MZ–FE) FUEL SYSTEM(2AZ–FE)

Equipment

Service Wire Harness	
Stopwatch	
Measuring Flask	
Ohmmeter	
Radiator cap tester	
Torque wrench	

SSM

	08850–00065 Butyl Tape Set	FUEL PUMP ASSY(1AZ–FE) FUEL TANK ASSY(1AZ–FE) FUEL PUMP ASSY(1MZ–FE) FUEL TANK ASSY(1MZ–FE) FUEL PUMP ASSY(2AZ–FE) FUEL TANK ASSY(2AZ–FE)