

















DRIVE SHAFT / PROPELLER SHAFT

PREPARATION






020U4–01

SST

	09240–00020	Wire Gauge Set	FRONT DRIVE SHAFT
	09520–00031	Rear Axle Shaft Puller	FRONT AXLE HUB SUB–ASSY LH
	09520–01010	Drive Shaft Remover Attachment	FRONT DRIVE SHAFT
	09520–24010	Differential Side Gear Shaft Puller	FRONT DRIVE SHAFT
	(09520–32040)	Shocker Set	FRONT DRIVE SHAFT
	09521–24010	Rear Axle Shaft Puller	FRONT DRIVE SHAFT
	09527–10011	Rear Axle Shaft Bearing Remover	FRONT DRIVE SHAFT
	09527–17011	Rear Axle Shaft Bearing Remover	FRONT AXLE HUB SUB–ASSY LH
	09527–30010	Rear Axle Shaft Bearing Remover	FRONT DRIVE SHAFT
	09608–16042	Front Hub Bearing Adjusting Tool	FRONT DRIVE SHAFT
	(09608–02021)	Bolt & Nut	FRONT DRIVE SHAFT
	(09608–02041)	Retainer	FRONT DRIVE SHAFT

	09608–32010	Steering Knuckle Oil Seal Replacer	FRONT AXLE HUB SUB–ASSY LH
	09628–10011	Ball Joint Puller	FRONT AXLE LH HUB BOLT REAR AXLE LH HUB BOLT
	09628–62011	Boll Joint Puller	FRONT AXLE HUB SUB–ASSY LH FRONT DRIVE SHAFT
	09726–40010	Lower Control Shaft Bearing Replacer	FRONT DRIVE SHAFT
	09930–00010	Drive Shaft Nut Chisel	FRONT AXLE HUB SUB–ASSY LH FRONT DRIVE SHAFT
	09950–00020	Bearing Remover	FRONT AXLE HUB SUB–ASSY LH FRONT DRIVE SHAFT
	09950–60010	Replacer Set	FRONT AXLE HUB SUB–ASSY LH
	(09951–00410)	Replacer 41	FRONT AXLE HUB SUB–ASSY LH
	(09951–00600)	Replacer 60	FRONT AXLE HUB SUB–ASSY LH
	09950–60020	Replacer Set No.2	FRONT AXLE HUB SUB–ASSY LH
	(09951–00790)	Replacer 79	FRONT AXLE HUB SUB–ASSY LH
	09950–70010	Handle Set	FRONT AXLE HUB SUB–ASSY LH
	(09951–07100)	Handle 100	FRONT AXLE HUB SUB–ASSY LH

Recomended Tools

	09011–12301	Socket Wrench 30 mm	FRONT AXLE HUB SUB–ASSY LH FRONT DRIVE SHAFT
	09040–00011	Hexagon Wrench Set	FRONT DRIVE SHAFT
	(09043–20060)	Socket Hexagon Wrench 6	FRONT DRIVE SHAFT
	09905–00012	Snap Ring No.1 Expander	FRONT DRIVE SHAFT
	09905–00013	Snap Ring Pliers	FRONT AXLE HUB SUB–ASSY LH

Equipment

Torque wrench	
Dial indicator with magnetic base	
Alingment tester	
Toe–in gauge	
Angle gauge	

Lubricant

Item		Capacity
Front drive shaft		
1MZ–FE	Outboard joint grease	205 – 215 g (7.2 – 7.6 oz.)
1AZ–FE/2AZ–FE	Outboard joint grease	190 – 200 g (6.7 – 7.1 oz.)
	Inboard joint grease	185 – 195 g (6.5 – 6.9 oz.)