

















BRAKE

PREPARATION




020X5–01

SST

	09023–00100	Union Nut Wrench 10 mm	BRAKE FLUID BRAKE BOOSTER ASSY FRONT BRAKE REAR BRAKE BRAKE ACTUATOR ASSY ABS & TRACTION ACTUATOR ASSY BRAKE MASTER CYLINDER SUB–ASSY
	09520–00031	Rear Axle Shaft Puller	SKID CONTROL SENSOR
	(09520–00040)	Shocker	SKID CONTROL SENSOR
	09521–00020	Drive Shaft Boot Clamping Tool	SKID CONTROL SENSOR
	09737–00011	Brake Booster Push Rod Gauge	BRAKE MASTER CYLINDER SUB–ASSY
	09737–00020	Brake Booster Push Rod Wrench	BRAKE MASTER CYLINDER SUB–ASSY
	09830–36010	Front Mounting Cushion Remover & Replacer	SKID CONTROL SENSOR
	09950–00020	Bearing Remover	SKID CONTROL SENSOR
	09950–50013	Puller C Set	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY
	(09951–05010)	Hanger 150	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY
	(09952–05010)	Slide Arm	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY

	(09953–05020)	Center Bolt 150	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY
	(09954–05021)	Claw No.2	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY
	09950–60010	Replacer Set	SKID CONTROL SENSOR
	(09951–00650)	Replacer 65	SKID CONTROL SENSOR
	09950–70010	Handle Set	SKID CONTROL SENSOR
	(09951–07100)	Handle 100	SKID CONTROL SENSOR
	09992–00242	Turbocharger Pressure Gauge	BRAKE FLUID
	09992–00350	Brake Reservoir Pressure Adapter	BRAKE FLUID

Recomended Tools

	09042–00010	Torx Socket T30	STEERING SENSOR BRAKE PEDAL SUPPORT ASSY
	09070–20010	Moulding Remover	BRAKE PEDAL SUPPORT ASSY
	09905–00013	Snap Ring Pliers	BRAKE MASTER CYLINDER SUB–ASSY

Equipment

Vernier calipers	
Dial indicator	
Torque wrench	
Brake drum gauge	

Lubricant

Item	Capacity	Classification
Brake fluid	–	SAE J1703 or FMVSS No. 116 DOT3