STARTING & CHARGING

030F8–03

SERVICE DATA

1AZ–FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 – 12.9 V at 20°C (68°F)

2AZ–FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 – 12.9 V at 20°C (68°F)

1MZ–FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 – 12.9 V at 20°C (68°F)