DTC P1633/89 ECM MALFUNCTION (ETCS CIRCUIT)

CIRCUIT DESCRIPTION

Refer to DTC P1129/89 on page 05–79.

DTC No.	DTC Detection Condition	Trouble Area
P1633/89	ECM inside error	•ECM

WIRING DIAGRAM

Refer to DTC P1125/41 on page 05–73.

INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand–held tester, as freeze frame data records the engine conditions when a malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air–fuel ratio lean or rich, etc. at the time of the malfunction.

CHECK AND REPLACE ECM