DTC C1201/51 ENGINE CONTROL SYSTEM MALFUNCTION

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1201/51	Conditions 1. and 2. continue for 5 sec.: 1. Engine speed: 500 rpm or more. 2. A trouble signal in the engine control system is input.	Engine control system

HINT:

If trouble occurs in the engine control system, the ECU prohibits TRAC and VSC control.

INSPECTION PROCEDURE

1	CHECK DTC FOR ENGINE(See page 05–290)

A	Normal Code
B	Malfunction Code

B → REPAIR ENGINE CONTROL SYSTEM ACCORDING TO CODE OUTPUT

A

CHECK AND REPLACE ECM