NAVIGATION SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0561A–03

1	Vehicle Brought to Workshop

2	Customer Problem Analysis (See page 05–1064)

3	Problem Symptom Confirmation (See page 01–31)

- Symptom does not occur (Go to step 4)
- Symptom occurs (Go to step 5)

4	Symptom Simulation (See page 01–31)

5	DTC Check (See page 05–1065)

- Normal code (Go to step 7)
- Malfunction code (Go to step 6)

6	DTC Chart (See page 05–1080)

Go to step 8

7	Problem Symptoms Table (See page 05–1089)

8	Terminal of ECU (See page 05–1086)

9	Indemnification of Problem

10	**Repair or Replace**

11	**Confirmation Test**

End