POWER WINDOW CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0563J–01

Troubleshoot in accordance with the procedure on the following pages.

1	VEHICLE BROUGHT IN

2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05–1152)

3	PROBLEM SYMPTOMS TABLE (See page 05–1155)

(a) Without applicable symptoms, proceed to ”A”.
(b) With applicable symptoms, proceed to ”B”.

B	Go to step 5

A

4	PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM

(a) On–vehicle Inspection (See page 70–1).
(b) Inspection (See page 70–2).
(c) Terminals of ECU (See page 05–1154).

5	ADJUSTMENT, REPAIR OR REPLACEMENT

END