05656–01

PROBLEM SYMPTOMS TABLE

Chart No.	Symptom	See page
1	Malfunction in speedometer	05–1181
2	Malfunction in tachometer	05–1185
3	Malfunction in water temperature receiver gauge	05–1187
4	Malfunction in fuel receiver gauge	05–1189
5	Entire combination meter does not operate	05–1191
6	Operating light control rheostat does not charge light brightness	05–1193
7	Key reminder warning buzzer does not sound	05–1196
8	Seat belt warning lamp for driver's seat does not operate	05–1198
9	Seat belt warning lamp for front passenger's seat does not operate	05–1201
10	Malfunction in clock display	05–1204
11	Malfunction in outside temperature display	05–1208
12	Malfunction in average vehicle speed display	05–1208
13	Malfunction in average fuel consumption/instantaneous fuel consumption display	05–1210
14	Malfunction in driving time display	05–1214
15	Malfunction in possible running distance display	05–1217
16	Multi–information display screen does not change when steering pad switch is operated	05–1222