0564Y–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected area	See page
All functions of wireless door lock control system do not operate (only wireless control function does not operate).	1. Transmitter battery 2. Door control transmitter 3. Door control receiver 4. DOME fuse 5. Instrument Panel J/B (Body ECU) 6. Unlock warning switch 7. Wireless door lock buzzer 8. Wire harness	05–1249