

FUEL PUMP ASSY (2AZ–FE)

COMPONENTS

110A4–01




Fuel Suction Plate Sub–assy
Fuel Pump Harness
Fuel Sender Gage Assy
Fuel Filter Assy
◆ O–ring
Fuel Pump
Fuel Pressure Regulator Assy
Fuel Pump Filter
◆ Clip
Cushion Rubber
Fuel Suction Support No.2
◆ Non–reusable part
A57123