
HEADLAMP DIMMER SWITCH ASSY

650CD–01

REPLACEMENT

1. REMOVE STEERING COLUMN COVER
(See page 50–6)



2. REMOVE HEADLAMP DIMMER SWITCH ASSY

(a) Disconnect the connector.

(b) Using a screwdriver, release the claw and pull out the headlight dimmer switch assy.

NOTICE:

Pressing the claw hard breaks the claw.

HINT:

Tape the screwdriver tip before use.