
WINDSHIELD WIPER SWITCH ASSY

66050–01

REPLACEMENT

1. REMOVE STEERING COLUMN COVER
(See page 50–6)



2. REMOVE WINDSHIELD WIPER SWITCH ASSY

(a) Disconnect the connector.
(b) Using a screwdriver, release the claw and pull out the windshield wiper switch assy.

NOTICE:
Pressing the claw hard breaks the claw.
HINT:
Tape the screwdriver tip before use.